

LO PRO MOORING COVER MOUNTING INSTRUCTIONS

As you install the snap-screws, the cover should be snapped into place.

1. Stretch out cover and pull tight to four corners, have someone hold down corners. Check all around for fit and make sure the corners are lined up with corner seam in cover. Check that the canopy rail-mounted bracket is centered in the pocket of the cover.
2. Use a screwdriver with Philips head #2 bit and install snap-screws in the front corner (screws are self-drilling). Screws should be centered on the trim. See diagram for order of installation. You would first install the side bottom four snaps (1a, 1b) on both starboard and port sides. You would then move to the stern (rear) and install the snaps on top of the rail in the corner (2a, 2b) on both sides. You would then install the snaps across the front of the boat on the trim piece (3). Then install the sides on the rail, moving from front to back (4a, 4b).
3. Locate loops in back by motor for attaching stretch cord around motor. On one side, pull the cord down and in and mark the location for the stainless eye hook installation. Install the screws into the eye hook. Do the same on the other side, (see diagram 5a, 5b).
4. Go to the front of the boat and unsnap enough of the snaps so you can crawl under the cover. Insert the poles into the snap in the vent and adjust the height of the pole so it is tight.

MAINTENANCE INSTRUCTIONS

Never store canvas when it is still damp. Periodically clean and treat your boat cover: remove dirt and dust by brushing with a soft bristle brush, then wet article and scrub with a soft-bristle brush using a mild soap. Never use bleach or harsh detergents. Spray the underside of the cover with Lysol or other disinfectant to prevent mildew. Lubricate snaps with petroleum jelly.

When completely dry, treat the outside of the cover with a UV inhibitor spray made for marine canvas, such as 303™ or AquaBlock™. This will also restore the water-repellency of the material and greatly increases the life of the cover. The cover does not need to be treated with the UV inhibitor spray when new, but rather after the first season or before the second season and once a year thereafter.

